

Rack Standoff Brackets

Part Number(s): RSB1A, RSB1B, RSB1C



INSTALLATION INSTRUCTIONS

CM565



Installing Standoff Brackets to Rack

Install brackets on rack using #12-24 X 1/2" Bonding Screws at desired RU location.

Notes: Minor flanges on brackets must be placed inward toward the rack center as shown.

Rack brackets must align horizontally.



For Technical Support: www.panduit.com/resources/install_maintain.asp

INSTALLATION INSTRUCTIONS

Securing Standoff Brackets

Using a phillips screwdriver through the front clearance holes in the bracket, tighten the #12-24 Bonding Screws. The clearance holes are obround and are at the top and bottom of the bracket.

Installing 1RU Horizontal Equipment

Install 1RU horizontal equipment (horizontal manager, patch panel, blanking panel, etc.) onto brackets using screws supplied with the piece of equipment being installed.



Completed Assembly

The Rack Standoff Brackets are designed to mount horizontal managers spaced off of rack equipment rails in order to match up the front of the horizontal managers with the front of the vertical managers.

Standoff bracket selection to have vertical cable manager and horizontal cable manager finger and door alignment			
PatchRunner High Capacity Vertical mounting position on rack	Fully back extended	Standard Mounting	Fully forward extended
Standoff Bracket to use	RSB1A	RSB1B	RSB1C



Installing Multiple RU Horizontal Equipment Using Rack Standoff Brackets

Multiple RU equipment will require (2) sets of Rack Standoff Brackets. These will be mounted on the outer ends of the equipment as shown.







For Instructions in Local Languages and Technical Support:

www.panduit.com/resources/install_maintain.asp