



Walker® Infloor Systems

Walkerbox® Floor Box Covers

895/896 Series


INSTALLATION INSTRUCTIONS

Walker® electrical systems conform to and should be properly grounded in compliance with requirements of the current National Electrical Code or codes administered by local authorities.

All electrical products may present a possible shock or fire hazard if improperly installed or used. Walker electrical products may bear the mark as UL Listed and/or Classified and should be installed in conformance with current local and/or the National Electrical Code.

1. Locate the outlet box and remove the top protector cap.
2. Pull necessary wires, following the National Electrical Code and/or local codes.
3. If using a box with adjusting screws, adjust the floor plate to the proper height.
4. Apply a bead of acrylic latex around the box, sealing the opening between the box and the adjacent concrete.

895 Series



5. Install a listed wiring device (not supplied by Walker), the fill-in plate (if required) and gasket.
6. Attach the floor cover (895 or 896) using the brass screws provided. Fasten securely.
7. Install the screw plugs or close covers when receptacle is not in use.

896 Series

